

UPC #010 and UPC #011 Installation

Place the starter cap over the pipe and slide the sleeve on. If one five foot section is not sufficient, then butt join two or more sleeves together and overlap barrier. To complete vapor barrier, seal all joints using tapes listed and labeled to UL 181-B.