


KOHLER® SERVICE PARTS

EcoCycle™
KITCHEN SINK

K-#	Self-Rimming	Tile-In	3-Hole	1-Hole
K-5854-**-AA	X		X	
K-5855-**-AA	X			X
K-5856-**-AA		X	X	
K-5857-**-AA		X		X



****Finish/color code must be specified when ordering.**

SERVICE PARTS

ITEM	PART NO.	DESCRIPTION
1	91921**	Colander
2	93576**	Cutting Board
3	93681**	Control Knob
4		Available In Service Kit Only
5		Available In Service Kit Only
6	93035**	Cover
7	93034-B**	Escutcheon
8	93037	Gasket
9	41948**	Strainer
10	48694	O-Ring
11		Available In Service Kit Only
12	93581	Screw
13	93608**	Outlet
14	41930	Gasket
15		Not Available As A Service Part
16	93854	Seal
17	93414	Bucket
18	93053	Housing
19	93052	Hinge
20	64212	Washer
21	90153	Locknut
22	93294	Handle
23	91932	Spacer
24	93044	Hinge
25	93108	Spacer
26	91780	Nut
27	69431	Screw
28	91920	Leg
29	64096	Screw
30	93039	Base
31	90993	Screw
32	93295	Hood
33	93050	Seal
34	93041	Chute
35		Available In Service Kit Only
36		Available In Service Kit Only
37		Available In Service Kit Only
38	41929	Washer
39	93584	Housing
40	93580	Gasket
41		Available In Service Kit Only
42		Available In Service Kit Only
43		Available In Service Kit Only
44		Available In Service Kit Only
45	41550	Gasket
46	41714-RP	Tailpiece
47	28504	Nut

SERVICE KITS

PART NO.	ITEM	QTY.	DESCRIPTION
93577**			Colander/Escutcheon Package
	1	1 ea.	Colander
	6	1 ea.	Cover
	7	1 ea.	Escutcheon
	8	1 ea.	Gasket
93582			Control Assembly
	4	1 ea.	Flange
	5	1 ea.	Gasket
	35	1 ea.	Washer
	36	1 ea.	Nut
	37	1 ea.	Housing
93609-RP			Stopper Assembly
	10	1 ea.	O-Ring
	11	1 ea.	Stopper
93319			Hardware Assembly
	20	10 ea.	Washer
	21	6 ea.	Locknut
	23	1 ea.	Spacer
	25	1 ea.	Spacer
	26	1 ea.	Nut
	27	4 ea.	Screw
	29	4 ea.	Screw
	31	8 ea.	Screw
93579			Control Body Assembly
	41	1 ea.	Body
	42	1 ea.	Gasket
	43	1 ea.	Plug
	44	1 ea.	Nut

**Finish/color code must be specified when ordering.