

Part 9 - Replacement Parts

ITEM#	DESCRIPTION	PART #
1	JUNCTION BOX COVER (w/SCREWS)	6060P-983
2	THERMOSTAT - UPPER	6060P-1008
	THERMOSTAT - UPPER ("U" MODELS ONLY)	6060P-001
3	THERMOSTAT - LOWER	6060P-1009
	THERMOSTAT LOWER ("U" MODELS ONLY)	6060P-002
4	THERMOSTAT PROTECTIVE COVER-UPPER	6060P-994
	THERMOSTAT PROTECTIVE COVER-UPPER (U-MODELS ONLY)	6060P-634
5	THERMOSTAT PROTECTIVE COVER-LOWER	6060P-952
	THERMOSTAT PROTECTIVE COVER-LOWER (U-MODELS ONLY)	6060P-636
6	ACCESS PANEL	6060P-187
7	SCREWS - ACCESS PANEL	6075P-006
8	MOUNTING BRACKET	6060P-955
	MOUNTING BRACKET ("U" models only)	6060P-956
9	ELECTRIC ELEMENT - 3000W	6060P-939
	ELECTRIC ELEMENT - 4500W	6060P-938
	ELECTRIC ELEMENT - 5500W	6060P-937
10	DRAIN VALVE	6070P-009
11	DIP TUBE - 40 GAL DIP TUBE - 52 GAL.	6060P-1034 6060P-1035
12	NIPPLE/HEAT TRAP	6060P-1038
13	TEMP/PRESSURE RELIEF VALVE	TP1700
14	JUNCTION BOX COVER W/ KNOCKOUTS (W/SCREWS)	6060P-982
15	PROTECTIVE INSULATION	6060P-965

PARTS FOR UNITS WITH BOLT-ON T-STAT BRACKETS ONLY-NOT SHOWN

16	THERMOSTAT MOUNTING BRACKET-BOLT-ON	6060P-633
17	SPACER	6060P-979
18	NUTS	6060P-935
19	ELEMENT PROTECTIVE COVER	6060P-997

WHL-026-A
11/16/18

Figure 9 - Replacement Parts - Staged Operation