




# PARTS

## INDOOR UNIT




Ref.	Description	Part number
1	Remote Control	9332820003
2	Remote Control Holder	9312653010
3	Bracket Panel	9332556001
4	Air Filter	9332549003
5	Intake Grille (FUJITSU)	9332818093
6	Receiver Window	9332546019
7	Front Panel	9332545012
8	Wire Cover	9332544008
9	Wire Shield	9332555004
10	Louver with Shaft cover	9333342009

INDOOR UNIT  
Control box




Ref.	Description	Part number	
21	Cover Shield	9332554007	
22	Control Box	9332542011	
23	Box Shield Assy	9332561005	
24	Main PCB (09)	9709170076	
24	Main PCB (12)	9709170083	
25	Terminal	9900720001	
26	Earth Terminal	9332553024	
27	Display Assy	9709173015	
28	Room Thermistor Holder	9316895003	
29	Thermistor Assy	9900714017	




Ref.	Description	Part number
31	Fan Motor	9603249007
32	Crossflow Fan Assy	9316830004
33	Bearing C Assy	9306628017
34	Casing Assy	9332613018

INDOOR UNIT  
Casing assy



Ref.	Description	Part number	
41	Casing	9332534009	
42	Motor Cover	9316601000	
43	Motor Cover	9316568006	
44	Casing Cover F	9332558005	
45	Casing Cover B	9332557008	
46	R and L Louver	9332535006	
47	Step Motor	9900725006	
48	Fan Guard	9332551006	
49	Drain Cap	9316177017	
50			

INDOOR UNIT  
Evaporator  
ASU9RL2



ASU12RL2

Ref.	Description	Part number
51	Evaporator Total Assy (09)	9316893641
52	Evaporator Total Assy (12)	9316893658
53	Earth Terminal	9316579002
54	Evaporator Holder R	9324154000
55	Evaporator Holder L	9324127004
56	Rear Bracket	9332540017