



Peerless® Series WB/WV/WBV™


All repair parts orders - no minimum charges.

Please order with code number.


All prices quoted are in U.S. dollars.

All prices subject to change without notice.

All prices F.O.B. Bally, PA



Steam Boiler



Water Boiler

8. REPAIR PARTS

Repair parts are available from your local PB Heat, LLC distributor or from Parts To Your Door at 1 (610) 916-5380 (www.partstoyourdoor.com).

Note: Remember to include the boiler model number and serial number when ordering parts.

Table 8.1

| Item No.* | Description | Additional Information | Stock Code |
|-----------|--|------------------------|------------|
| 1 | Block Assembly – Water – WBV-03(Open) | - | 90190 |
| | Block Assembly – Water – WBV-04 (Open) | - | 90191 |
| | Block Assembly – Water – WBV-05 (Open) | - | 90192 |
| | Block Assembly – Water – WBV-03 (Closed) | - | 90348 |
| | Block Assembly – Water – WBV-04 (Closed) | - | 90349 |
| | Block Assembly – Steam – WBV-03 (Open) | - | 90707 |
| | Block Assembly – Steam – WBV-04 (Open) | - | 90708 |
| 2 | Target Wall | - | 50795 |
| 4 | Swing Door Hinge | - | 90538 |
| 5 | Burner Mounting Plate Assembly | - | 90158 |
| - | Burner Mounting Plate Insulation | - | 50794 |
| 6 | Burner Mounting Plate Rope Seal | - | 51211 |
| 7 | Steel Cover Plate (Front) – Water | - | 99812 |
| 8 | Rubber Gasket (Front) – Water | - | 51800 |
| 9 | Tankless Coil – WBV-03 – Water | - | 90637 |
| | Tankless Coil – WBV-04 – Water | - | 90534 |
| | Tankless Coil – WV-05 – Water | - | 90534 |
| | Tankless Coil – WBV-03 & 04 – Steam | - | PP-1011R |
| 10 | Flue Collector Plate Blanket Seal | - | 90999 |
| 11 | Flue Collector Cover Plate – WBV-03 | - | 90565 |
| - | Flue Collector Cover Plate – WBV-04 | - | 90566 |
| 11A | Top Outlet Flue Collector Plate – WV-05 | - | 90562 |
| 12 | Rope Seal | - | 51209 |
| 13 | Rear Outlet Cover Plate | - | 90563 |
| 14 | Flue Collar Adapter – WBV-03 & 04 – Water | - | 90568 |
| | Flue Collar Adapter – WBV-03 & 04 – Steam | - | 90386 |
| 15 | Jacket Assembly – Water – WBV-03 | - | 90291 |
| | Jacket Assembly – Water – WBV-04 | - | 90288 |
| | Jacket Assembly – Water – WV-05 | - | 90290 |
| | Jacket Assembly – Steam – WBV-03 | - | 90292 |
| | Jacket Assembly – Steam – WBV-04 | - | 90289 |
| 16 | Steel Cover Plate (Rear) | - | 90141 |
| 17 | Rubber Gasket (Rear Section Plate) | - | 51673 |
| 18 | Flue Outlet Gasket | - | PP5011 |
| - | Pressuretrol | - | 51324 |
| - | Drain Valve | - | 50764 |
| - | Relief Valve – Water | - | 50501 |
| - | Pop Safety Valve – Steam | - | 50510 |
| - | Insulation Hardware | - | 91218 |
| - | Limit Control, Beckett AquaSmart 7600A | - | 50337 |
| - | Immersion Well, Beckett 7600T | - | 50341 |
| - | Immersion Sensor, Beckett 7600P | - | 50339 |
| - | Limit Control with Sensor, Hydrolevel HydroStat 3250 | - | 50343 |
| - | Immersion Well, Hydrolevel | - | 50723 |

Part numbers may be subject to change without notice.

*See Figures 2.1 & 2.2 on page 5 for boiler exploded view.