

GUH97T VARIABLE SPEED 2-STAGE GAS FURNACES 97T CRITICAL PARTS LIST

DESCRIPTION	PART NUMBER	USED ON THESE MODELS
102712-01 Wheel-Blower 10 X 9 X 1/2	69W52	GUH97T045B3M, GUH97T070B3M, GUH97T090C3M
102703-02 Wheel-Blower 11 X 11 X 1/2	69W50	GUH97T090C5M, GUH97T110C5M, GUH97T135D5M
102809-02 Hose Drain UH	71W36	GUH97T(ALL)M
102809-03 Hose Drain	98W72	GUH97T(ALL)M
610587-01 Module Kit	22U07	GUH97T045B3M
610587-48 Module Kit	22U08	GUH97T070B3M
KIT, MOTOR MODULE	24K46	GUH97T090C3M
KIT, MOTOR MODULE	24K47	GUH97T090C5M
610587-52 Module Kit	22U12	GUH97T110C5M
KIT, MOTOR MODULE	24K48	GUH97T135D5M
Inducer Assembly	81W45	GUH97T(ALL)M
ARM-MOTOR MTG (4)	49L97	GUH97T(090,110)C5M, GUH97T135D5M
610588-01 Motor Kit	10B66	GUH97T045B3M, GUH97T070B3M, GUH97T090C3M
610588-02 motor kit	10B67	GUH97T(090,110)C5M, GUH97T135D5M
LB-107597A Blower Hardware Kit	71M48	GUH97T(045,070,090)B3M
MOUNT-MOTOR	18M68	GUH97T045B3M, GUH97T070B3M, GUH97T090C3M,
MOUNT-MOTOR	32M17	GUH97T(090,110)C5M, GUH97T135D5M
102907-01 Roll Out Switch (210F)	71W49	GUH97T(ALL)M
103181-02 VALVE-GAS (2 STG NAT)	83W12	GUH97T(ALL)M
102317-01 SWITCH-INTERLOCK	51W15	GUH97T(ALL)
609627-01 Kit-Gas Valve Barbed Fitting	92W78	GUH97T(ALL)
LB-100797 HARN-WIRE	27M25	GUH97T(ALL)
107583-01 HARNESS, WIRING	27M56	GUH97T045B3M
107585-03 HARNESS, WIRING	24M63	GUH97T(070,090)B3M, GUH97T(090,110)C5M
27M1101 HARNESS-WIRING (BLOWER V-SPEED)	27M11	GUH97T(ALL)
607308-20 KIT-IGNITION CONTROL	19V33	GUH97T(ALL)
602866-04 Burner Assy (045)	69W87	GUH97T045B3M
ASSY BURNER (6)	69W88	GUH97T070B3M
ASSY BURNER (8)	69W89	GUH97T090C3M, GUH97T090C5M
ASSY BURNER (10)	69W90	GUH97T110C5M
ASSY BURNER (12)	69W91	GUH97T135D5M
625974-01 HT EX EL297 / 97G2-UHE/V-045	25F21	GUH97T045B3M
625974-02 HT EX EL297 / 97G2-UHE/V-070	25F22	GUH97T070B3M
625974-03 HT EX EL297 / 97G2-UHE/V-090	25F23	GUH97T090B3M, GUH97T090C5M

625974-04 HT EX EL297 / 97G2-UHE/V-110	25F24	GUH97T100C5M
625974-05 HT EX EL297 / 97G2-UHE/V-135	25F25	GUH97T130D5M
LB-94726T HOUSING-BLOWER	70W40	GUH97T045B3M, GUH97T070B3M, GUH96T090C3M
LB-94726X HOUSING-BLOWER	70W42	GUH97T(090,110)C5M, GUH97T135D5M
LB-74940B Flame Sensor Kit	69W43	GUH97T(ALL)M
104549-15 Pressure Switch 2-STG-.80/- .50	14A57	GUH97T045B3M
104549-20 Pressure Switch 2-STG-.95/- .55	25B93	GUH97T070B3M, GUH96T090C5M
104549-03 Pressure Switch 2-STG-.90/- .50	14A45	GUH97T090B3M, GUH97T090C5M
104549-18 PRESSURE SWITCH 2STG 1.00/.55	25B82	GUH97T110C5M
104549-07 Pressure Switch 2-STG-.85/- .45	14A49	GUH97T135D5M
42J3201 TRANSFORMER	42J32	GUH97T(ALL)M
LB-112237B IGNITER	70W16	GUH97T(ALL)M
102857-08 Control-Limit (165F)	75W15	GUH97T070B3M
102857-07 Control-Limit (175F)	73W20	GUH97T045B3M, GUH97T090C3M
102857-05 Control-Limit (150F)	73W18	GUH97T(090,110)C5M
102857-04 Control-Limit (145F)	71W44	GUH97T135D5M
605099-07 DRAIN TRAP (GOODY BAG)	95W17	GUH97T(ALL)M

